

Scimitar

- These plans may be freely distributed but all rights remain with Art Applewhite Rockets © 2006 www.artapplewhite.com
- Print on 110 lb cardstock. Crease all the dashed lines with a ballpoint pen and a ruler.
- Cut out the TOP. Cut only on the solid lines with a good pair of scissors.
- Cut out the Launch Rod hole marked "LR" in the TOP with a sharp craft knife.
- Fold on the dashed lines away from the printed side.
- Spread white glue evenly over the Glue Tab and attach it to the underside of the TOP to form a closed corner.
- Cut out the BOTTOM. Fold on the dashed lines toward the printed side.

- Spread glue evenly over the back (non-printed side) of the three tabs.
- Glue the BOTTOM to the TOP with all the edges matching up and the Launch Rod Holes lining up.
- Cut out the MOTOR MOUNT, fold it into a 3 sided tube and glue it together.
- Put glue on the small triangles at the end of the MOTOR MOUNT.
- Slide the glued end of the MOTOR MOUNT into the hole in the BOTTOM until it makes contact, centered evenly, with the inside of the TOP.
- Put a fillet of glue around the joint between the MOTOR MOUNT and the BOTTOM.
- To fly, loosely friction fit a motor into the MOTOR MOUNT.
- Use Estes A10-PT motors only.

