

Scimitar Version 2.0

- These plans may be freely distributed but all rights remain with Art Applewhite Rockets © 2008 www.artapplewhite.com
- Print on 110 lb cardstock. Crease all the dashed lines with a ballpoint pen and a ruler.
- Cut out the TOP. Cut only on the solid lines with a good pair of scissors.
- Cut out the Launch Rod hole marked "LR" in the TOP with a sharp craft knife. Fold on the dashed lines away from the printed side.
- Spread white glue evenly over the Glue Tab and attach it to the underside of the TOP to form a closed corner.
- Cut out the BOTTOM. Fold on the dashed lines toward the printed side.
 - Spread glue evenly over the back (non-printed side) of the three tabs.
 - Glue the BOTTOM to the TOP with all the edges matching up and the Launch Rod Holes lining up.
 - Cut out the MOTOR MOUNT, fold on the dashes lines toward the printed sides
 - Form the MOTOR MOUNT into a 3 sided tube and glue it together.
 - Put glue on the small triangles at the end of the MOTOR MOUNT.
 - Slide the glued end of the MOTOR MOUNT into the hole in the BOTTOM and up to the inside of the TOP.
 - Put a fillet of glue around the joint between the MOTOR MOUNT and the BOTTOM.
 - Use Estes A10-0T, A10-3T, A10-PT motors

